

Protecting What Is Most Important

Patient Security System

The McRoberts Patient Security system offers the most comprehensive security for individuals in multiple hospital departments, including Pediatrics, Geriatrics, Mental Health, and Emergency. Hospitals can choose department level perimeter protection, with the option of expanding to a facility-wide solution that includes staff emergency response capabilities. Because both applications work with the same infrastructure, you can be confident that a McRoberts security system is a sound investment for the long term.

Perimeter Protection

Patients at risk for abduction or elopement wear a small, lightweight, water resistant tag. Monitored patients can move around freely but are prevented from leaving a designated area. Key perimeter exits are continually monitored by the system. Normal hospital traffic flow is not affected by the security system; however, if a monitored patient approaches a controlled door, its lock is activated. If the door is open, a visual or audible alarm will sound. Alarms can be forwarded to wireless staff pagers and phones. In addition to the standard patient tag, there are optional cut and tamper resistant tags, which provide a more robust barrier to unauthorized removal.

Facility-Wide Supervision

The Patient Security system can be enhanced to provide facility-wide supervision. At-risk patients wear a supervised tag which emits pulsed signals that are monitored by a network of receivers throughout the facility. The software will alarm if the tag pulses are not received by the system.



Emergency Response

With enhanced facility-wide supervision, your Patient Security system can now also be used as a Staff Emergency Response system, enabling healthcare workers to call for assistance from anywhere within the facility. By simply pushing the button on a small staff pendant tag, an alarm message is immediately displayed in the software. The message identifies the individual in distress and the precise location of the alarm. The system then continues to track the staff member's movement, ensuring a quick locate response time.

Intuitive Software

The McRoberts software displays customized floor maps of your facility and visual event notification. Designed for ease-of-use, the software includes handy Wizards to step staff through common tasks. The system can integrate with a wide range of other systems and devices, including access control systems, video surveillance, fire alarms, nurse call systems, pagers and magnetic door locks. This gives you a single point from which to manage patient and staff security.





Comprehensive Support Program

All our systems, MyChild® Infant Security, Pediatric Security, Wander Prevention, Staff Security, and Asset Tracking, are backed by the industry's most comprehensive customer support program. Our suite of value added service solutions is tailored to each customer. We continually invest in state of the art equipment, training and processes that improve our ability to deliver quality services that meet or exceed regulatory requirements (FDA, AHA, HIPAA, TJC).

Every McRoberts' security system comes with a complete installation, implementation and support package that includes:

- A one-year limited warranty on all McRoberts supplied hardware, software, and network components.
- 24 / 7 Toll free Customer Support Hotline for the lifetime of the system.
- In-Service training provided by Registered Nurses.

About McRoberts Security Technologies

McRoberts Security Technologies has been configuring and installing health-care security systems since 1992. McRoberts builds customized security solutions that work with "best of breed" third-party products and can often leverage existing infrastructure so we can deliver the best tailored security system for your facility. With hundreds of systems installed in hospitals across North America, McRoberts has established itself as a trusted industry leader with the experience, expertise, and a proven track record that healthcare professionals can rely on.

McRoberts Security Technologies is a subsidiary of McRoberts Protective Agency, Inc., which has been setting the standard in uniform guard services since 1876.

For more information, contact us:
1985 Swarthmore Avenue
Lakewood, NJ USA 08701
tel: 800 . 776 . 7328
fax: 732 . 886 . 1749
sales@mcrobertssecuritytechnologies.com
www.mcrobertssecuritytechnologies.com

Key System Advantages

Ease of Use

Our system's interface is intuitive and easy to use, requiring minimal administration and training. The software provides visual and audible alarms, with at-a-glance multi-level facility floor maps displaying monitored areas and tag status.

Effective Security

For your peace of mind, the system continuously monitors its own functionality. The infrastructure is installed out of sight. The advanced software provides unique user names, multiple levels of password protected security control, network supervision, audit trail, and advanced reporting capabilities.

Maximum Flexibility

Our system permits staff, patients, and visitors to move freely throughout the facility while simultaneously notifying staff when a monitored patient is in a detection zone. The system is highly configurable, giving system administrators the flexibility to program whether an exit will sound alarms or not, depending on the time of day.

Companion Tag Mode allows specific pendants to be assigned to designated patient tags so staff or family members escorting patients now have automatic door bypass when those tags leave together.

Elevator Detection Zones can be configured per elevator bank or inside the individual elevator car. When installed inside the elevator car, an alarm occurs only if the patient actually enters the car, and won't affect the operation of the other elevators in the bank.